

ARCS PROCEDURE:	CYCLING POWER ON THE WSI USING BOTH BLUE AND WHITE BOXES AT NAURU	PRO(WSI)-013.000
Author: T. Tooman		May 4, 1999 Page 1 of 2

Cycling Power on the WSI Using Both Blue and White Boxes at Nauru

I. Purpose:

Describes the steps for cycling the power on the WSI using both blue and white boxes at Nauru.

II. Cautions and Hazards:

None.

III. Requirements:

None.

IV. Procedure:

A. Shutting down the blue box inside the I-Van:

1. Press 'X' on the keyboard.
2. Wait until you see C:\RUNWSI on the monitor.
3. Open up the blue box.
4. Eject the MO disk.
5. Move the key located below the monitor in the center of a black box to the **OFF** position.
6. Move the Sensor ACP ON/OFF key to the **OFF** position. The Sensor ACP is the second box above the MO drive.
7. Move the Occultor ACP ON/OFF key to the **OFF** position. The Occultor ACP is located one box above the MO drives.
8. Turn off the MO drive. Switch on right hand side.
9. Turn off the GPS. GPS is located on the top of the blue box. Hold down the red key for 3 seconds.

B. Shutting down the white box outside:

1. Locate the power box on the outside of the I-Van. It is located on the side of the I-Van that faces the instrument field.
2. Locate the one orange power cord that is labeled WSI. The plug should be plugged into a white plug. Label on the cable that came out of the WHITE plug as _____.
3. Unplug the cable.

ARCS PROCEDURE:	CYCLING POWER ON THE WSI USING BOTH BLUE AND WHITE BOXES AT NAURU	PRO(WSI)-013.000
Author: T. Tooman		May 4, 1999 Page 2 of 2

C. Powering up the white box:

1. Locate the power box on the outside of the I-Van. It is located on the side of the I-Van that faces the instrument field.
2. Plug in both cables that you unplugged in Step 2. Remember to plug in the cable you noted in Step 2 into the appropriate ORANGE and WHITE plugs. This is VERY important to put these back exactly as you unplugged them.

D. Powering up the blue box in the I-Van:

1. Turn on the GPS. GPS is located on top of the blue box. Hold down the red key for 3 seconds. A display should appear on the handset.
2. Open up the blue box.
3. Move the key located below the monitor in the center of a black box to the ON position. The computer should come up and you will see stuff on the monitor. Continue with the next step.
4. Move the Sensor ACP ON/OFF key to the ON position. The Sensor ACP is the second box above the MO drive.
5. Move the Occultor ACP ON/OFF key to the ON position. The Occultor ACP is located one box above the MO drives.
6. Turn on the MO drive. Switch on right hand side.
7. Push the MO disk in.
8. Do you see a picture on the monitor? Did the occultor move? Please call if you do not see a picture or if the occultor did not move.

V. References:

None.

VI. Attachments:

None.